

PURE EZ LIFT

Product # 701

All-natural floating lift station degreaser

Keeps lift station surfaces free of grease. As waste water levels rise and fall, heavy grease deposits are deposited on lift station walls. It coats the walls and surfaces of the lift station to remove heavy grease accumulations quickly and safely. The special non-emulsifying formula floats on the surface of the water, so it continues to remove deposits as the water level changes. Contains a soybean oil derivative which does not evaporate as fast as other solvents, so it remains on the surface of wastewater longer to penetrate fats, grease and dirt and strip them away from surfaces. Will not disrupt the natural biological digestion of bacteria in the lift station.

Use in Lift stations:

Keeps walls, pumps hoses clean and functioning properly

Effective Against:

- Floating grease balls
- Heavy oil accumulation
- Annoying odors

Features and Benefits

- Float on the surface so it will rise and fall with the level of the wastewater
- Quickly dissolves heavy grease and fat accumulations in a lift station
- Creates an odor absorbing barrier to control odors and leaves a pleasant citrus scent
- Color indication lets you know when you need to add more
- 100% natural biodegradable formula will not interfere in lift station bacteria

Properties

Appearance.....	Green liquid
Fragrance	Citrus scent
Specific gravity.....	0.88
Flash point	165 ° F
VOC content (% by wt.).....	5-15 %
Solubility	Insoluble in water
Stability at 70 °F	1 year

Directions

Use approximately 1/2 gallon for every square foot of wastewater surface area.

Active Ingredients

	CAS Number
Methyl Ester of Soybean Oil.....	67784-80-9
d'Limonene	5989-27-5
Green Dye.....	No CAS number

Safety

Caution: Combustible. May be harmful if swallowed. May irritate eyes and skin. Keep out of the reach of children.

DOT Shipping (ground transportation)

Proper Shipping Name:	None
Class:	None
ID Number:	None
Package Group:	None

Quantities

55 gallon
30 gallon
5 gallon
4 x 1 gallon/case
6 x 1 gallon/case

